Table 3: Recommendations from the 2014 LMWUA WTP Audit report (the status label from Table 1 is used to indicate progress)

ID	Area	lto indicate progress)	Recommendation		10
	Alta	15500	Recommentation	Priority	Status
MEN001	Information systems	Daily plant operational data sheets are currently stored in an electronic format at the council office. However, the collected data is not utilised to identify possible efficiency improvements	Utilise plant operational data to optimise chemical dosing and plant performance (ie monitor plant flows and configurations and chemical usage trends and compare to water quality)	High	С
MEN002	Information systems	Currently there are no standard operating procedures that exist for the plant. General operating procedures are being developed in unison with the alliance	Develop operating procedures that cover the following areas: • Plant operations • Routine/scheduled maintenance • Plant troubleshooting • Laboratory tasks/procedures	High	I
			velop 12 SOPs which have been		
	Information	m. Ground-truthing is still re Instantaneous and daily	Perform daily chemical		1
MEN003	systems	chemical dose rates are currently not monitored or compared to instantaneous and daily plant flows.	drop rates. This will allow operators to monitor pump performance and compare against instantaneous plant flow rate to calculate chemical dose rate • Record daily (24 hr) chemical usage and plant flow. This will allow actual chemical dose rate to be calculated This information is useful for plant performance optimisation and troubleshooting	High	
Note		e being performed, however	daily chemical usage not yet ca	lculat	ed.
MEN004	Information systems	Currently, no equipment maintenance plan exists	 Develop an equipment maintenance plan that covers: Equipment scheduled and reactive maintenance Critical spares list Protocol for identifying failed equipment and response 	High	Ι

	Note: A maintenance schedule will be prepared as part of the NSW Health support project (task 4a in Table 5).							
MEN005	Information systems	Plant pressure vessels currently do not have calibration certificates displayed	Perform pressure vessel calibration and display certificates on site.	High	I			
Note	Note: Still outstanding.							
MEN006	Process unit – Aeration, coagulation	Poly aluminium chloride and potassium permanganate are both dosed through the same diffuser into the top of the aeration stairway	Perform jar tests to determine optimum coagulant dose rates and mixing configurations. Investigate (by performing jar tests) using separated dosing diffusers for improved efficiency of both coagulation and metal removal	Medium	С			
MEN007	Wash water recovery	Wash water is directed to the sedimentation ponds for recovery. A concentration of contaminants unable to be removed in the sedimentation process may occur increasing the load on the filters	Consider a sedimentation stage with long residence times prior to returning the wash water to the inlet works. This may be achieved through installing baffles in the lagoon to reduce short circuiting	Medium	1			
Note	: will be consid	lered as part of the WTP Up	grade (current stage – concept o	desigr	i)			
MEN008	Sludge handling	Sludge is pumped out of the sedimentation ponds and disposed of onsite	Sample and test the sludge prior to removing from the lagoon to ensure it is appropriate to apply/dispose on site. The sludge should be tested for metals, organics, pH and moisture content	High	С			
	•	being carted to the tip, biose	olids testing for disposal at the ti	p is no	ot			
MEN009	Iron and manganese issues	The plant experiences high manganese levels	Perform jar testing to determine optimum manganese removal dosing configurations	High	С			
MEN010	Safety	The eyewash station experiences low pressure.	Investigate methods to maintain a higher pressure in the eyewash station water line. This may include: • Booster pump • Constant pressure valve	High	С			
MEN011	Security	The clear water tank lids/covers are unsecured.	Ensure access to the treated water tanks are secured and locked	High	С			

MEN012	Security	Critical equipment is currently exposed	Install a door with lock on the existing treated water delivery pumps to reduce risk of pump damage	High	С
MEN013	Signage	The plant entrance gates do not contain the appropriate signs	 Erect signs on the entrance gates that display the following information: Chemical hazard signs of the chemicals contained on site Plant contact details 	High	С
MEN014	Reservoir hypochlorite	The sodium hypochlorite dosing line and dosing point is exposed and unsecured. There is the potential for damage for damage, contamination or vandalism	Cover and secure the dosing line and dosing point.	High	С
MEN015	Reservoir hypochlorite	The sodium hypochlorite bulk storage tank and fill point is not currently bunded. Any chemical leaks/spills will be unable to be contained	Install a chemical bund in the hypochlorite dosing room. Consider constructing a bunded fill point for the delivery vehicle	High	С